Gasket is required for under floor air applications. (provided by others)

Apply pedestal adhesive between perimeter head and cut panel. (Optional)

Perimeter Head

Field Head

Stringer