



Note: For Plenum spaces apply a bead of caulk at slab and foundation joints. Apply gasket material at floor interface to curb.

Note: Optional air seal may be specified for plenum spaces created with bare TecCrete.