



Note: For plenum spaces apply a bead of caulk at slab and foundation joints.

Note: Optional air seal may be specified for plenum spaces created with bare TecCrete