

TecCrete - Grounding to Building

NOTE 1: Electrical contractor to provide & install a 1/4"-20-unc bolt (Min.), a #6 bare ground wire and appropriately sized connector.

NOTE 2: Exact location & quantities of ground connectors to be determined by electrical engineer/contractor.

NOTE: BOTTOM OF PANEL DIRECTLY CONTACTS WITH PED HEAD.

