



Walls are secured at ceiling level, or stabilized by attached perpendicular walls, then powder actuated pins can be used to fasten floor track to the surface of the TecCrete panel in combination with construction adhesive. Final wall calculations and attachment method to be provided by others.

NOTE: This is a common field application, job site testing should be completed for your specific application. We recommend that any attachments to the floor panel be done no less than 3" from the edge of the panel.