



Note: For plenum spaces apply a bead of caulk at slab and foundation joints. Apply gasket material at floor interface and wall.

Note: Optional air seal maybe specified for plenum spaces created with bare TecCrete